# **Owner's Manual**

# M.2 NGFF PCIe SSD (M-Key) PCI Express Card

Model: PCE-1M2-PX4

Este manual esta disponible en español en la página de Tripp Lite: www.tripplite.com/support

Ce manuel est disponible en français sur le site Web de Tripp Lite : www.tripplite.com/support

Русскоязычная версия настоящего руководства представлена на веб-сайте компании Tripp Lite по adpecy: www.tripplite.com/support

#### **PROTECT YOUR INVESTMENT!**

Register your product for quicker service and ultimate peace of mind. You could also win an ISOBARGULTRA surge protector—a \$100 value! www.tripplite.com/warranty





1111 W. 35th Street, Chicago, IL 60609 USA www.tripplite.com/support

Copyright © 2017 Tripp Lite. All rights reserved.

#### **Product Features**

- Enhance your PC's speed and increase internal storage by adding an M.2 PCle SSD (M-Key) adapter
- Supports 2242, 2260 and 2280 M.2 drive types
- PCI Express 4-Lane (x4) interface is compatible with (x4), (x8) and (x16) slots
- PCle M.2 SSD speeds provide ultra-fast data access to your computer
- Install your OS on your M.2 PCle drive, while using larger platter drives for bulk storage
- Compatible with PCle 3.0 motherboards; backward compatible with PCle 2.0 and PCle 1.0
- · Plug-and-play; no software or drivers required
- · No external power required

#### **Package Contents**

- PCE-1M2-PX4
- Screws (x2)
- SSD standoff nut
- Owner's Manual

## **System Requirements**

- Computer with an available PCI Express (PCIe) expansion slot (x4, x8, x16)
- M.2 NGFF PCle Drive with an M-Key or B + M-Key connector; not compatible with M.2 NGFF SATA SSDs
- Compatible with Windows® (XP and later), Mac® (OS X® 10.0 and later)
- Supports 2242, 2260 and 2280 M.2 drive types

#### Installation

#### Notes:

- PCI Express cards are static sensitive devices that require proper handling. An Anti-Static ESD Wrist Strap (such as Tripp Lite's P999-000) or similar device should always be used when handling.
- Handle the card with care when installing, holding it by the edges and not the PCle interface connectors.
- When disconnecting the drive, go through the proper disconnection steps of your operating system to safely remove it. Removing the drive prior to proper disconnection can result in losing or corrupting data stored on the drive.
- If your drive has not been formatted yet, you will first need to format it using your computer's disk management utility in order to copy and access files.
- Place your SSD next to the M.2 SSD connector on the PCle adapter, matching up the drive installation holes. Insert the standoff into the hole that matches the size of your drive. Secure the standoff to the board using one of the included screws and nut.
- Slide the M.2 connector on the SSD drive into the M.2 receptacle on the PCle adapter.
  - **Note:** The connector on the M.2 SSD is keyed so the drive will only fit one way.
- Hold down the drive toward the mounting standoff, and secure it in place using the second included screw. Your M.2 drive is now installed.
- 4. Turn off the computer you are installing the PCle card in. Unplug its power cord and disconnect all peripheral devices (e.g. monitor, keyboard, mouse, printer, etc.) from it.
- Referring to your computer's technical documentation, remove the cover from your computer.
- Locate an available PCI Express slot (x4, x8 and x16 slots supported). Remove the metal bracket from the back of the computer to allow for insertion of the card.

## Installation

- Gently insert the PCle interface connector on the adapter into the PCle slot, making sure it connects securely and evenly.
- 8. Fasten the metal bracket to the back of the computer.
- Place the cover back onto the computer, and re-connect its power cords and peripheral devices. Your adapter is now ready to use.

## **Specifications**

Drive Connection	M.2 NGFF PCIe (M-Key)
PCle Card Connection	(x4) PCI Express—Male
Supported SSD	2242, 2260, 2280
Operating Temperature	50° to 122°F (10° to 50°C)
Operating Humidity	10% to 80% RH

### **Warranty and Product Registration**

#### 1-Year Limited Warranty

TRIPP LITE warrants its products to be free from defects in materials and workmanship for a period of one (1) year from the date of initial purchase. TRIPP LITE's obligation under this warranty is limited to repairing or replacing (at its sole option) any such defective products. To obtain service under this warranty, you must obtain a Returned Material Authorization (RMA) number from TRIPP LITE or an authorized TRIPP LITE service center. Products must be returned to TRIPP LITE or an authorized TRIPP LITE service center with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase. This warranty does not apply to equipment, which has been damaged by accident, negligence or misapplication or has been altered or modified in any way.

EXCEPT AS PROVIDED HEREIN, TRIPP LITE MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some states do not permit limitation or exclusion of implied warranties; therefore, the aforesaid limitation(s) or exclusion(s) may not apply to the purchaser.

EXCEPT AS PROVIDED ABOVE, IN NO EVENT WILL TRIPP LITE BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OF THIS PRODUCT, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE. Specifically, TRIPP LITE is not liable for any costs, such as lost profits or revenue, loss of equipment, loss of use of equipment, loss of software, loss of data, costs of substitutes, claims by third parties, or otherwise.

#### **Product Registration**

Visit www.tripplite.com/warranty today to register your new Tripp Lite product. You'll be automatically entered into a drawing for a chance to win a FREE Tripp Lite product!\*

\* No purchase necessary. Void where prohibited. Some restrictions apply. See website for details.

### **Warranty and Product Registration**

#### FCC Notice, Class B

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications to this equipment not expressly approved by Tripp Lite could void the user's authority to operate this equipment.

## WEEE Compliance Information for Tripp Lite Customers and Recyclers (European Union)



Under the Waste Electrical and Electronic Equipment (WEEE) Directive and implementing regulations, when customers buy new electrical and electronic equipment from Tripp Lite they are entitled to:

- Send old equipment for recycling on a one-for-one, like-for-like basis (this
  varies depending on the country)
- Send the new equipment back for recycling when this ultimately becomes waste

## **Warranty and Product Registration**

Use of this equipment in life support applications where failure of this equipment can reasonably be expected to cause the failure of the life support equipment or to significantly affect its safety or effectiveness is not recommended.

Tripp Lite has a policy of continuous improvement. Specifications are subject to change without notice.





1111 W. 35th Street, Chicago, IL 60609 USA www.tripplite.com/support

8

17-02-307 93-36BF\_revA